

VetteCargoNets™ C5 Mid Barrier Net (Part # C5MB01)

Photo A: (C5 Mid Barrier Net Hook Attachment Locations (two each side))



Driver side



Passenger side

Photo B: (plastic hook provided for VetteCargoNets™ attach points) Keep steel pins aligned parallel to each other and not bent or crooked before inserting into carpet.

