

## VetteCargoNets™ C6 Behind Seat Net (Part # C6BS01)

Photo A: (C6 Behind Seat Net Hook Attachment Locations (two)) Driver Side Shown, same for passenger side. Note the angle of the plastic hooks. This is needed to compensate for a horizontal force when stretching the bungee between them and a vertical force from any items placed in the net.



Photo B: (plastic hook provided for VetteCargoNets™ attach points) Keep steel pins aligned parallel to each other and not bent or crooked before inserting into carpet.

