

VetteCargoNets™ C6 Rear Barrier Net (Part # C6RB01)

The VetteCargoNets™ Rear Barrier Net is a direct replacement for a lost or broken factory net and factory attachment points/hooks are used and required but not provided and it is assumed that your factory hooks are in place. No additional hooks needed. For the C6 there are only hooks for the top of the net.



(Factory Rear Hooks for C6. Only used for VetteCargoNets™ product “Rear Barrier Net”. Factory Hooks Not Included - Assumed they are currently installed from factory in your C6)



C6 Factory Rear Net Hook