

VetteCargoNets™ C7 Aft Mid Barrier Net

(Part # C7AMB01)

Photo A: (C7 Mid Barrier Net Hook Attachment Locations (two each side))



Driver side



Passenger side

Note: Per the photos, this net can be installed along with the lower factory privacy screen.

Photo B: (plastic hook provided for VetteCargoNets™ attach points) Keep steel pins aligned parallel to each other and not bent or crooked before inserting into carpet.

