

VetteCargoNets™ C7 Rear Barrier Net (Part # C7RB01)

The VetteCargoNets™ Rear Barrier Net is a direct replacement for a lost or broken factory net and factory attachment points/hooks are used and required but not provided. It is assumed that your factory hooks are in place. No additional hooks needed. For the C7 there are only hooks for the top of the net.



(Factory Rear Hooks for C7. Only used for VetteCargoNets™ product "Rear Barrier Net". Factory Hooks Not Included - Assumed they are currently installed from factory in your C7)



C7 Factory Rear Net Hook